



## **GB** Instruction for use



- ❶ Tripod thread protective cap
- ❷ Assembly screw
- ❸ Tripod adapter
- ❹ Tripod plate

1. Screw the tripod adapter (3) onto the tripod plate (4).
2. Remove the protective cap from the tripod thread (1) of your binocular. Turn counter clockwise or simply pull the cap off.
3. Now mount the binocular with the assembly screw (2) onto the tripod adapter.



ANL1916500GB1103BRESSER



**BRESSER**

*Tripod adapter* • Art. No. 19-16500